

2016 HEAT TRANSFER VINYL HOUSEHOLD IRON APPLICATION INSTRUCTIONS

SISER MATERIALS THAT CAN BE APPLIED WITH A HOUSEHOLD IRON



Adheres to: 100% cotton,
100% uncoated polyester,
poly/cotton blends
Peel HOT or COLD



Adheres to: 100% cotton,
100% uncoated polyester,
poly/cotton blends
Peel HOT or COLD



Adheres to: 100% uncoated polyester,
poly/cotton blends, lightly siliconed nylon,
leather
Peel HOT or COLD



Adheres to: 100% cotton,
100% uncoated polyester,
poly/cotton blends
Peel COLD



Adheres to: 100% cotton,
100% uncoated polyester,
poly/cotton blends
Peel COLD



Adheres to: 100% cotton,
100% uncoated polyester,
poly/cotton blends
Peel COLD



Adheres to: 100% cotton,
100% uncoated polyester,
poly/cotton blends
Peel WARM



Adheres to: 100% cotton,
100% uncoated polyester,
poly/cotton blends
Peel COLD

BEFORE APPLICATION

Preheat iron to cotton setting ° Place fabric for heat application on a firm surface (such as a cutting board) ° Preheat garment for 2-3 seconds

WEEDING AND APPLICATION



1 Cut in reverse



2 Weed (pick)



3 Place transfer on the
garment as desired



4 Use a cover sheet, such as
parchment paper or a
heat transfer cover sheet



5 Use FIRM pressure
for 10 seconds
cover entire image

DO NOT SLIDE IRON



6 Remove the clear
polyester carrier



7 Use a cover sheet and
reheat for another
5-10 seconds



8 Wait at least 24 hours
before first wash

RECOMMENDED ACCESSORIES

Siser weeder
Multipurpose paper
Heat transfer cover sheet
Heat Transfer Pillow

WASHING INSTRUCTIONS

Machine wash WARM or HOT with mild detergent
Wait 24 hours before first wash



Do not bleach



Do not dry clean



Dry at normal
Dryer settings



Iron friendly