

Siser® EasyPSV™ Chalk Board is a matte pressure sensitive calendared vinyl used for a wide variety of indoor and outdoor applications such as menu boards, signs, and decorations.

Indoor Durability	Up to 1 year depending on climate and UV exposure.
Thickness	5.0 mil (76.2 micron)
Adhesive	Removable
Liner	90# Layflat
Minimum, Application Temperature	+40° F
Shelf Life	1 year when stored at 70° F and 50% relative humidity.

Materials that can be decorated with *EasyPSV* Removable include: Painted drywall, glass/mirrors, wood, plastic, metal, ceramic
Some common projects include: Wall decals, signs, labels

**Not recommended for use near flame/ heat source, or with microwave, and dishwasher.*

Surface Prep Instructions

For best adhesion, remove any dirt, dust, grease, etc to prepare the surface you want to decorate with *EasyPSV*. The following cleaning method is not recommended for porous surfaces such as unfinished/untreated wood. It is recommended that all other surfaces be spot tested with care before cleaning the entire application area.

Non-porous surfaces can be cleaned with a mix of approximately 2 parts water and 1 part isopropyl alcohol (70% or higher for best results) or non-ammonia based window cleaner. Use a microfiber or lint free towel to clean the application area with the mixture. Paper towel is not recommended since it will leave behind small bits of paper that can become trapped under the *EasyPSV* during application. Ensure the area is completely dry before applying.

**The cleaning method outlined above is subject to modification and not always suitable for every substrate.*

The purchaser should independently determine with their own testing to use this method or not on a case by case basis.

Application Instructions

1. Place *EasyPSV* with the liner side down and cut your design. (DO NOT reverse/mirror your design.)
2. Weed excess vinyl.
3. Remove the application tape's paper liner. Place tape on top of *EasyPSV* and burnish with a squeegee.
4. Lift the application tape and *EasyPSV* away from the paper liner to expose the removable adhesive.
5. Place the application tape on your desired object and burnish with a squeegee to fully adhere the design.
6. Gently peel away the application tape, leaving just your *EasyPSV* design on the object.

Removal Instructions

Guaranteed for 1 year. Later removal may require an adhesive remover to clean all the adhesive from the surface. If the *EasyPSV* is stubbornly sticking, the heat from a hair dryer or garment steamer can help loosen the adhesive. However, heating is not recommended for glass due to possible shattering. To remove Removable *EasyPSV* from glass, saturate the decal with soap and water. Cover with plastic wrap and let sit for a few hours before attempting to remove. An adhesive remover may still be required to clean all adhesive from the surface after removing the *EasyPSV*.

**The removal instructions outlined above are subject to modification and not always suitable for every substrate.*

The purchaser should independently determine with their own testing to use this method or not on a case by case basis.

Storage Instructions

For best results, avoid direct sunlight and extreme temperatures. Ideally, temperatures should not surpass 70° F and 50% relative humidity. When stored properly, *EasyPSV* Chalk Board has a shelf life of 1 year.

Please Note:

The technical information contained in this document is issued to the best of our knowledge. Data represents averages and is not intended for use as a specification. These values are intended only as a source of information. They are given without guarantee and do not constitute a warranty. Due to the variety of projects, substrates, surface cleaners, and more individual circumstances we recommend a test should be conducted before each process, and the information provided be used as only a guideline.